Nero

BIANCA TALL BASIN MIXER

SPECIFICATION

PRODUCT CODE	YSW3215-01A
WELS RATING	5 STAR 5L/MIN
WATERMARK LICENSE	WM-060073
TEMPERATURE RATING	MIN 1℃-MAX 75℃
PRESSURE RATING	MIN 150KPa-MAX 500KPa

FINISH

|		
	NR321501aCH	chrome
	NR321501aBRG	brushed rose gold
	NR321501aMB	matte black
	NR321501aBN	brushed nickel
	NR321501aGM	gun metal
	NR321501aBG	brushed gold

MAINTENANCE AND CARE

All surfaces should be cleaned with mild liquid detergent or soap and water.

Do not use cream cleaners or citrus based cleaning products, as they are abrasive.

Use of unsuitable cleaning agents may damage the surface.Any damage caused in this way will not be covered by warranty

PACKAGING INCLUDES

- 1x basin mixer
- 2x flexible hose
- 1x threaded pipe
- 1x fixing nut
- 1x steel washer
- 1x rubber washer
- 1x fixing bolt (for fixing nut)
- 1x allen key

Dimensions are nominal measurements only.

100   25°
10°
273.5   227
50   179

15 YEARS WARRANTY

W AS/NZS 3718 WM-060073

WATER RATING www.waterrating.gov.au 5.0 litres per minute In accordance with AS/NZS 6400 Licence No.1225 YINSHENGWANG SANITARY WARE LIMITED COMPANY

Versions: 2019.11.26

www.nerotapware.com.au

INSTALL INSTRUCTION

Mixer
Threaded pipe
O-ring
Rubber washer
Galvanised washer
Plastic fixing nut (PFN)

1. Fit the O-ring into the groove in the underside of the mixer body.
2. Screw the flexible hoses into the mixer body, and fully hand tighten.
3. P ass the tail of flexible pipes through the hole on the bench top from above, and place the mixer in position on the bench top. Inspect to see if any alteration to the existing supply pipe work is required. Make any necessary alterations.
4. Tighten the fixing nut to treaded pipes compressing the galvanized washer and rubber washer from the under-side of the counter.
5. Check that the mixer body is correctly positioned, fully tighten the fixing nut screw and fixing bolts firmly..
6. Connect the water supply pipes to the tail of flexible hoses with the hot water and cold water.
7. Test for any leaks.

EXPLOSIVE VIEW

1. Body	11. Base ring
2. Cartridge	12. O-ring
3. Retaining nut	13. Rubber washer
4. 0-ring	14. Steel washer
5. Cartridge cover	15. Treaded pipe
6. Grub screw	16. Fixing nut
7. Cap	17. Fixing bolt
8. Handle	18. Flexible hose
9. Aerator	
10. Locating pin	